



High precision cutter belonging to the small tungsten carbide cutters family. The oval geometry provides excellent resistance, while the head dimensions offer the best advantage to access small areas. The short blade length transmits the operator's full cutting force. The flush cutting edge is suitable to perform clean cuts on the hardest wires. The cutter is equipped with an ESD ergonomic slim handle which allows an excellent grip, suitable to environments and to components susceptible to electrostatic discharge. The tungsten carbide insert blades are hardened to 82HRC. Handle material: Ergonomic Slim - Thermoplastic and Elastomer + PP compound

General Info

|                |                                      |
|----------------|--------------------------------------|
| Product Number | 16950-12                             |
| Category       | Cutters > Industrial<br>MedTech Line |
| EAN            | 4251909512057                        |



Find 16950-12 on  
[finescience.com](https://finescience.com)

Technical Info

|                        |                                               |                 |      |
|------------------------|-----------------------------------------------|-----------------|------|
| Shipping Weight        | 90 g                                          | Net Weight      | 83 g |
| Package Size           | 1 Pc.                                         | Unit of Measure | EA   |
| Minimum Order Quantity | 1                                             |                 |      |
| Alloymaterial          | Carbon Steel w/ Tungsten Carbide Cutting Edge |                 |      |
| Bladematerial          | Tungsten carbide (TX)                         |                 |      |
| Cuttingedge            | 9.5 mm                                        |                 |      |
| Cuttingedgetext        | Flush                                         |                 |      |
| Length                 | 12 cm                                         |                 |      |
| Esdsafe                | Yes                                           |                 |      |
| Headshape              | Small, oval                                   |                 |      |
| Jointaction            | Single                                        |                 |      |