



Slim High Precision Tungsten Carbide Cutter - Small, Tapered



High precision cutter belonging to the small Tungsten Carbide cutters family. The angled tapered geometry provides excellent ergonomics combined with good resistance, while the tip dimensions offer the best advantage to access small areas. The short blade length transmits the operator's full cutting force. The flush cutting edge is suitable to perform clean cuts on the hardest wires. The cutter is equipped with an ESD ergonomic slim handle which allows an excellent grip, suitable to environments and to components susceptible to electrostatic discharge. The Tungsten Carbide insert blades are hardened to 82HRC. Handle material: Ergonomic Slim - Thermoplastic and Elastomer + PP compound

General Info

Product Number	16951-12
Category	Cutters > Industrial MedTech Line
EAN	4251909512064



Find 16951-12 on
[finescience.com](https://www.finescience.com)

Technical Info

Shipping Weight	92 g	Net Weight	85 g
Package Size	1 Pc.	Unit of Measure	EA
Minimum Order Quantity	1		
Alloymaterial	Carbon Steel		
Bladematerial	Tungsten carbide (TX)		
Cuttingedge	13 mm		
Cuttingedgetext	Full-Flush		
Length	12 cm		
Esd safe	Yes		
Headshape	Small, tapered		
Jointaction	Single		