



The reflection-free and high-contrast 4.3-inch display ensures relaxed work. The HD camera arranged centrally under the display enables easy orientation. A magnification of up to 12x can be selected continuously or in increments by touching the magnifying glass symbol. You can also choose between five display modes: True color, contrast-enhanced black/white, white/black, black/yellow and yellow/black. In addition, the brightness of the display can be dimmed if there is a high sensitivity to glare. The integrated LED lighting can be switched off for use on glossy surfaces. With the photo function, the live image seen through the magnifying glass can be saved as a photo on an inserted SD card. The images can also be easily transferred to a computer via a USB connection. In addition, the USB connection to the computer enables the live image of the magnifying glass to be transferred to the PC monitor, so the mobilux can also be used as a screen reader. The 'mobilux digital' program supplied must first be installed on the computer. Delivery incl. USB cable, SD memory card (incl. software), protective hard foam case, lanyard and cleaning cloth. Mains adapter for EU, GB, US, AUS included.

General Info

Product Number	28070-50
Category	Lab Accessories > Magnifiers
EAN	4026158316417



Find 28070-50 on
[finescience.com](https://www.finescience.com)

Technical Info

Shipping Weight	1324 g	Net Weight	236 g
Package Size	1 Pc.	Unit of Measure	EA
Minimum Order Quantity	1		
Feature	Touchscreen		
Fieldofview	Variable		
Magnification	4 -15x		
Screensize	11 cm (4.3 inch)		
Screenresolution	480 x 272 px		
Workingdistance	Variable		